



Harbour Butt Hinge

How To



Features & Benefits


- Low profile, captured design specifically for PVC-U doors. Dedicated performance, unobtrusive appearance
- Integral fixing lugs and 7 screw fixing positions. Optimal stability and strength
- Security anti-lift pin. Prevents intruder from removing the pin and lifting out the door
- Available in 2 different chamfers (O and 5 degrees). Works with square and chamfered profiles
- Colour coordinated cover caps. Perfectly matching components, even down to the smallest details
- 2D adjustable with supplied allen keys.
 Allows for final tweaking and alignment





Harbour Butt Hinge

How To



Adjustment Instructions

Compression Adjustment +0.5mm -0.5mm (5mm Allen key)

- Remove the top cap
- Check pin alignment via the mark on top of the pin. If the mark is pointing towards the door sash, the adjustment is in neutral setting
- To increase compression, turn the pin so that the alignment mark is moved towards the door frame
- To reduce compression, turn the pin so that the alignment moves away from the frame

Vertical Adjustment +3.0mm -0.0mm (5mm Allen key)

- Remove the bottom cap
- To raise the door sash, rotate the vertical adjustment screw clockwise. Ensure that all other hinges are adjusted equally
- screw anti-clockwise. Ensure that all other hinges are adjusted equally

Lateral Adjustment +2.0mm -2.0mm (4mm Allen key)

- Remove the side cover caps
- Rotate the lateral adjustment drives in the direction required.
- Ensure that each pair of alignment marks are at the same point

WARNING

- Its is not recommended to fully adjust either one adjuster only or one hinge only. Adjustments should be made gradually, aligning each pair of marks on each hinge until the



